

Care & Maintenance

Fabric-Wrapped Surfaces

Fabric-wrapped panels and upholstered acoustic surfaces keep their appearance with routine, gentle care. Because the fabric facing is acoustically transparent and stretched over a soft core, avoid pressing hard or saturating the surface.

Routine Cleaning

- Vacuum regularly using low suction and a soft brush or upholstery attachment, working in the direction of the weave.
- Do not press the vacuum tool hard against the panel; the core beneath the fabric is soft and compressible.

Spot Cleaning

- Blot spills immediately with a clean, dry, white cloth. Do not rub, which can spread the stain and distort the weave.
- For water-safe fabrics, spot clean with a cloth lightly dampened with a mild, water-based upholstery cleaner or a solution of mild soap and water. Blot gently, working from the outside of the spot inward.
- Do not saturate the fabric or allow moisture to soak into the core.
- Allow the panel to air dry completely before returning it to service.

Deeper Cleaning

- For heavier soiling, use a manufacturer-approved fabric cleaner appropriate to the fabric's cleaning code (W, S, WS, or X). Always test on an inconspicuous area first.
- Professional low-moisture or dry cleaning is recommended for stubborn or widespread staining.

Precautions

- Avoid abrasive cleaners, solvents, and bleach unless expressly permitted by the fabric manufacturer's cleaning code.
- Keep sharp objects away from the fabric facing to prevent snags, pulls, and tears.
- Protect panels from prolonged direct sunlight, which can fade fabric over time.